



OWNERS MANUAL PARTS LIST



701 Lenham Ave. - P.O. Box 647 Cooperstown, ND 58425 Office (701) 797-2700 Fax (701) 797-2584 Toll Free (800) 797-1883 www.sheyennemfg.com

Table of Contents

Торіс	Page No.
Table of Contents	1
Introduction	2
Serial Number Location	3
Warranty	4 - 6
Safety, Specifications and Decals	7
Features	8
General Operations	9
Dismounting A Wheel	10 - 12
Off-loading	12 - 13
Loading and Mounting A Wheel	13
Miscellaneous and Lubrication	14
Part Section	15 - 17

INTRODUCTION

CONGRATULATIONS on your choice of the Wheel EZ, wheel changer for your farm shop, implement dealership, construction business or job site repair! This useful device has been designed and manufactured to function safely, efficiently and trouble free.

Safe operation of the machine requires that the operator reads and understands the information in this manual. Further discussion of safety will be done on page 7.

Keep this manual handy for reference.

SERIAL NUMBER LOCATION

Give your dealer the serial number of your Wheel EZ when ordering parts or requesting service or other information.

The serial number plate is located as indicated below.



It is the responsibility of the **purchaser** and all **operator's** to **read and understand** this manual. It has been prepared to assist in the safe operation and suitable maintenance of this device. The information is applicable to the product at the time of manufacture and does not include modifications or updates made thereafter.

a	1 N T 1		
Orio	1 Number		
OCHA	I INDITION I		

WHEELEZ WARRANTY

SHEYENNE TOOLING & MANUFACTURING warrants each new product to be free from defects in material and workmanship. This warranty is applicable only for the normal service life expectancy of the machine or components, not to exceed **twelve consecutive months** from the date of delivery of the new SHEYENNE TOOLING & MANUFACTURING product to the original purchaser.

Genuine SHEYENNE TOOLING & MANUFACTURING replacement parts and components will be warranted for 90 days from date of purchase, or the remainder of the original equipment warranty period, whichever is longer.

Under no circumstances will it cover any merchandise or components thereof, which in the opinion of the company, has been subject to negligent handling, misuse, alteration, an accident, or if repairs have been made with parts other than those obtainable through SHEYENNE TOOLING & MANUFACURING.

Our obligation under this warranty shall be limited to repairing or replacing, free of charge to the original purchaser, any part that in our judgment shall show evidence of such defect, provided further that such part shall be returned within thirty (30) days from date of failure to SHEYENNE TOOLING & MANUFACTURING.

This warranty shall not be interpreted to render us liable for injury or damages of any kind or nature to person or property.

Except as set forth above, SHEYENNE TOOLING & MANUFACTURING shall have no obligation of liability of any kind on account of any of its equipment and shall not be liable for special or consequential damage. SHEYENNE TOOLING & MANUFACTURING makes no other warranty, express or implied, and, specifically, SHEYENNE TOOLING & MANUFACTURING disclaims any implied warranty of merchantability of fitness for a particular purpose. Some states or provinces do not permit limitations or exclusions of implied warranties of incidental or consequential damages, so the limitations or exclusions in this warranty may not apply.

This warranty is subject to any existing conditions of supply, which may directly affect our ability to obtain materials or manufacture replacement parts.

SHEYENNE TOOLING & MANUFACTURING reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligations to owners of units previously sold.

No one is authorized to alter, modify or enlarge neither this warranty nor the exclusions, limitations and reservations.

I have read and understand the above instructions and warranty. Warranty is invalid until all three copies are completed and signed. Customer copy retained, dealer copy in dealer's possession and manufacturer's copy returned.

Date Purchased	Dealership	
Serial Number		
Customer Signature	Date	
Dealer Signature	Date	

Customer Copy

(Keep in this book)

Please enter information below and SAVE FOR FUTURE REFERENCE

WHEELEZ WARRANTY

SHEYENNE TOOLING & MANUFACTURING warrants each new product to be free from defects in material and workmanship. This warranty is applicable only for the normal service life expectancy of the machine or components, not to exceed **twelve consecutive months** from the date of delivery of the new SHEYENNE TOOLING & MANUFACTURING product to the original purchaser.

Genuine SHEYENNE TOOLING & MANUFACTURING replacement parts and components will be warranted for 90 days from date of purchase, or the remainder of the original equipment warranty period, whichever is longer.

Under no circumstances will it cover any merchandise or components thereof, which in the opinion of the company, has been subject to negligent handling, misuse, alteration, an accident, or if repairs have been made with parts other than those obtainable through SHEYENNE TOOLING & MANUFACURING.

Our obligation under this warranty shall be limited to repairing or replacing, free of charge to the original purchaser, any part that in our judgment shall show evidence of such defect, provided further that such part shall be returned within thirty (30) days from date of failure to SHEYENNE TOOLING & MANUFACTURING.

This warranty shall not be interpreted to render us liable for injury or damages of any kind or nature to person or property.

Except as set forth above, SHEYENNE TOOLING & MANUFACTURING shall have no obligation of liability of any kind on account of any of its equipment and shall not be liable for special or consequential damage. SHEYENNE TOOLING & MANUFACTURING makes no other warranty, express or implied, and, specifically, SHEYENNE TOOLING & MANUFACTURING disclaims any implied warranty of merchantability of fitness for a particular purpose. Some states or provinces do not permit limitations or exclusions of implied warranties of incidental or consequential damages, so the limitations or exclusions in this warranty may not apply.

This warranty is subject to any existing conditions of supply, which may directly affect our ability to obtain materials or manufacture replacement parts.

SHEYENNE TOOLING & MANUFACTURING reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligations to owners of units previously sold.

No one is authorized to alter, modify or enlarge neither this warranty nor the exclusions, limitations and reservations.

I have read and understand the above instructions and warranty. Warranty is invalid until all three copies are completed and signed. Customer copy retained, dealer copy in dealer's possession and manufacturer's copy returned.

Date Purchased	Dealership	
Serial Number		
Customer Signature	Date	
Dealer Signature	Date	

Dealer Copy



PLEASE ENTER INFORMATION BELOW AND RETURN TO SHEYENNE TOOLING AND MANUFACTURING

WHEEL EZ WARRANTY

SHEYENNE TOOLING & MANUFACTURING warrants each new product to be free from defects in material and workmanship. This warranty is applicable only for the normal service life expectancy of the machine or components, not to exceed twelve consecutive months from the date of delivery of the new SHEYENNE TOOLING & MANUFACTURING product to the original purchaser.

Genuine SHEYENNE TOOLING & MANUFACTURING replacement parts and components will be warranted for 90 days from date of purchase, or the remainder of the original equipment warranty period, whichever is longer. Warranty is not applicable for normal wear and usage.

Under no circumstances will it cover any merchandise or components thereof, which in the opinion of the company, has been subject to negligent handling, misuse, alteration, an accident, or if repairs have been made with parts other than those obtainable through SHEYENNE TOOLING & MANUFACTURING.

Our obligation under this warranty shall be limited to repairing or replacing, free of charge to the original purchaser, any part that in our judgement shall show evidence of such defect, provided further that such part shall be returned within thirty (30) days from date of failure to SHEYENNE TOOLING & MANUFACTURING.

This warranty shall not be interpreted to render us liable for injury or damages of any kind or nature to person or property.

Except as set forth above, SHEYENNE TOOLING & MANUFACTURING shall have no obligation of liability of any kind on account of any of its equipment and shall not be liable for special or consequential damage. SHEYENNE TOOLING & MANUFACTURING makes no other warranty, express or implied, and, specifically, SHEYENNE TOOLING & MANUFACTURING disclaims any implied warranty of merchantability of fitness for a particular purpose. Some states or provinces do not permit limitations or exclusions of implied warranties of incidental or consequential damages, so the limitations or exclusions in this warranty may not apply.

This warranty is subject to any existing conditions of supply, which may directly affect our ability to obtain materials or manufacture replacement parts.

SHEYENNE TOOLING & MANUFACTURING reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligations to owners of units previously sold.

No one is authorized to alter, modify or enlarge neither this warranty nor the exclusions, limitations and reservations.

I have read and understand the above instructions and warranty. I have also read the owner's manual and understand all safety precautions. Warranty is invalid until all three copies are completed and signed. Customer copy retained, dealer copy in the dealer's possession and the manufacturer's copy returned.

Date Purchased		Dealership	
Customer Information:	Serial NumberName (Please Print)		
	Address		
			, Zip Code
	E-Mail (If Applicable)		
	Signature		, Date
Dealer Signature		Date	

Please return via; fax, regular mail or e-mail; to: fax number - (701) 797-2584 address --

PO Box 647
Cooperstown, ND 58425
e-mail — warranty@sheyennemfg.com

Safety:

The steps to dismount a wheel begins on page 10. This safety information also begins with dismounting. It is strongly recommended that the tractor, sprayer, etc. be jacked up enough to have the wheel off the floor. Use appropriate sized jack, block other wheels to avoid rolling and use normal safety practices.

The Wheel EZ changer can then be moved into position. Spread the sets of rollers far apart enough to push the changer up on both sides of the wheel and make contact with the white polyurethane panel at the base. Loosely put the safety chain around the wheel, hooking both sides into the slotted plates provided. Lift the sets of rollers to the point the wheel is about equally supported by he Wheel EZ changer and the tractor. Avoid upward pressure on the lug bolts or space for the wheel to drop when the last lug bolt is removed.

Lifting or lowering will take up slack on the chain. Make adjustments if needed, but don't leave the chain too slack. The chain must be reasonable tight when moving away from the dismount.

The Wheel EZ changer, whether empty or loaded is quite heavy. Do not be under it or have feet, hands, etc. under it.

When loading it with a forklift or bucket be certain to engage the forks or the bucket lip fully. Lift and back away, keeping the load low.

To safely off-load the wheel, select a wall or sturdy structure to lean the wheel against. Lower the wheel to the floor far enough away from the wall to form a 15 to 20 degree angle when the safety chain is unhooked and the wheel is leaned to the wall.

For loading, moving and mounting use all of these steps in reverse order. Read and follow all the instructions and Figures on pages 8 - 14. Be sure to use the safety chain at all times.

Specifications:


The empty Wheel EZ changer weighs 665 pounds.

It is 60" high, 51" deep, front to back and 54" wide when closed to it's narrowest.

Decals:

The wheel changer has one identification decal on the top crossbar and the serial number decal that is shown on page 3.

Features



Adjusts for Larger or Smaller Wheels Mounts or Dismounts Wheels

Wheel Changer and Handler

General Operations

The main features of the Wheel EZ changer are shown in **Fig. 1**, page 8. Become familiar with them. The operations information here will use terms from that page.



Figure 2.

The upper horizontal arrows here indicate that the crossbar has telescoping extensions that accommodate wider or narrower wheels. The vertical arrows make similar adjustment for taller of shorter wheels. The lower arrow shows the adjustable section that accommodates smaller or larger wheels on or near floor level.





Figure 3.

The above illustration views the wheel changer from the opposite side. It shows the point were the two sections telescope. **Fig. 1** on page 8 and the detail below, show provision for three ways to move the wheel changer. Forklift tines in the tubes are the probably the best way to handle the loaded wheel changer. Exercise safety when preforming any of these operations!



DISMOUNTING A WHEEL



Figure 4.

Fig. 4 shows the Wheel EZ positioned to remove a wheel from a sprayer. It is required that the wheel being removed is **not** bearing load. This is done by jacking the tractor, sprayer, etc. up. Do not attempt to lift the whole machine. The Wheel EZ is designed to lift the wheel only. The changer is adjustable (up and down) and movable left - right and toward the machine and away. The vertical adjustment is accomplished by turning the lead screw in.



Figure 5.See the red arrow above. As the outer section comes in, it lifts the wheel.



Figure 6.

An air wench is helpful in this step. Use this adjustment to carefully support and position the wheel. Avoid any damage to lug bolts as weight shifts from the tractor to the wheel changer and the wheel is moved away. Make <u>sure</u> the restraining chain is hooked and is holding the wheel upright, **Fig. 6**. Then it is safe to move the wheel away.



Figure 7. An air wrench does the lifting and lowering.

DISMOUNTING A WHEEL (cont.)



Figure 8.

View of the safety chain securing the wheel to the upright post and the cross arms.



Figure 9.

Fig. 9 shows a forklift being used to move a wheel.




Figure 10.

Detail of the adjustable section that lifts the wheel. It also accommodates larger and smaller wheels.



Figure 11.

Each set of rollers pivot to support different sized wheel.

DISMOUNTING A WHEEL (cont.)



Figure 12. Other ways to transport

Fig. 12 covers the other two ways of moving the wheel and the wheel changer.

The red arrows point to two lift plates. A loader mounted bucket can be placed as the white arrows show, over the tubes and under the lift plates. The bucket edge needs to be fully under the lift plates for safe operation.

The wheel and wheel changer can also be manually moved over any smooth hard surface by using the four caster wheels mounted under the unit (blue arrows above) and close-up below.



Figure 13. Caster wheel

OFF-LOADING A WHEEL



Figure 14. Positioning

If the wheel needs to be off-loaded, move to a location that can safely support the wheel in a nearly vertical position.



Figure 15. Lowering

Lower the wheel by spreading the lower section until the weight of it rests on the floor or ground. Unhook the safety chain and lean the wheel against a wall or similar sturdy structure, **Fig. 15**. Move the Wheel EZ back.

OFF-LOADING A WHEEL (cont.)



Figure 16. Safely supported

LOADING A WHEEL

To load a wheel resting on the floor, do steps shown in **Fig. 16, 15** and **14** and the associated descriptions in reverse order.

MOUNTING A WHEEL

The Wheel EZ is uniquely useful when mounting a wheel! The vertical height, the left – right location and the rotation of the wheel are all readily adjustable. All of this is done without much manual effort and while the wheel is safely restrained!

The vertical height is set by turning the lead screw in or out as shown earlier in the dismounting procedure (pages 10 - 12).

The left – right is done manually or by side-shift, if your fork-lift has that feature.

Rotating the wheel to get good hole alignment is done by using one or the other posts on the changer. See Fig. 17.



Figure 17. Pry Post



Figure 18. Rotating the wheel Rotating the wheel to align rim holes with the tapped holes in the hub or rim holes with captive lug studs.

MISCELLANEOUS



Figure 19. Bin

A chain bin is mounted on the mast as shown. It can also serve as a tool holder while working with the Wheel EZ. Lug bolts or lug nuts can be put here to keep them off the floor.

LUBRICATION



Figure 20. Zerks

The rollers have grease zerks at each end as shown in Fig. 20. Grease periodically.



Figure 21.


The lead screw has a grease zerk as shown above.


There is also a zerk to grease the sliding tube at the other end of the tube shown.




Figure 22.

Each caster wheel has two grease zerks as shown here.







from Sheet 1 & 2 Detail of Item 7 Wheel EZ

Sheet 3 of 3

4 2 9



701 Lenham Ave. - P.O. Box 647
Cooperstown, ND 58425
Office (701) 797-2700
Fax (701) 797-2584
Toll Free (800) 797-1883
www.sheyennemfg.com